



1500 ALUMINUM SWINGER INSTALLATION INSTRUCTIONS



INFORMATION SHEET

LIFT SPECIFICATIONS	
PILING DIAMETER	10" MIN.
PILING HEIGHT ABOVE SURFACE	48" MIN.
MAXIMUM WIDTH AND LENGTH WATERCRAFT	84" WIDTH 192" LENGTH
MAXIMUM WEIGHT	1500 lbs.




WHEN CHOOSING LOCATION FOR YOUR LIFT, MAKE SURE THE LOCATION HAS ADEQUATE CLEARANCE TO ROTATE YOUR WATERCRAFT. REFER TO THE ILLUSTRATION FOR THE MINIMUM CLEARANCE REQUIREMENTS FOR YOUR PERSONAL WATERCRAFT.

REVISED 2/22/2017

DATE: 2/18/05




STEP 1: SWINGER SEAWALL MOUNT INSTALLATION

1. The first step in installing your lift is attaching the seawall mount to the seawall.
2. Place mount in the desired location and square up the edge with the front of the seawall.
3. Mark and drill the holes using the locations in the seawall base plate. (Use as many holes as possible)
4. Anchor to concrete pad with minimum 4" anchor bolt.




"A" HOLES ARE FOR Ø.75 BOLTS
 "B" HOLES ARE FOR Ø.625 BOLTS

REVISED 2/22/2017



STEP 1: SWINGER PILING MOUNT INSTALLATION


Figure A



1. The first step in installing your lift is attaching the piling mount to the piling. You will need a 5/8" drill bit, 5 bolts (5/8" diameter and 2" min. longer than your piling diameter), 2 bolts (min. of 4" longer than your piling diameter) and wrenches to fit the 5/8" bolts.
2. Your piling height should be a min. 48" from the decking surface. (AS SHOWN IN FIGURE C)
3. The piling mount bracket has one end with the channel extending below the hinge bracket. That is the bottom of the piling mount. The bottom of the swivel hinge should be 14" from the decking or surface that the lift will be rotating over. (AS SHOWN IN FIGURE A)
4. Place the piling mount against the piling, use a level to get the piling mount square and plumb on the piling. (AS SHOWN IN FIGURE A) After you achieve this, mark the 2 holes in the front of the channel for drilling. "Do not mark the six holes in the ears yet"
5. Remove the piling mount and drill the hole as straight as possible with a 5/8" diameter drill bit.
6. Then attach the piling mount to the piling using (2) 5/8" bolts 4" (min.) longer than the piling diameter. (Not included)
7. After attaching piling with (2) 5/8" bolts, square and plumb piling mount into place. (2X4 shims may be needed to accomplish this.)
8. After achieving step 7, mark the six remaining holes in the piling ears and drill with 5/8" diameter drill.



Figure C



REVISED 2/22/2017

3"X3"X1/4" SQUARE WASHER





Figure B


STEP 2: MAST INSERTION

1. Insert the mast into the top of the housing making sure that the two holes in the bottom of the mast are oriented as shown in the illustration below.
2. The two holes in the bottom of the mast are offset to provide counterlever support when the arms are attached and the load of the watercraft is applied.



STEP 3: MAST INSTALLATION

1. Position housing close to piling mount bracket, attached to piling.
2. Stand housing and mast assembly upright. (As shown in figure B)
3. Align swinger brackets on the housing above swinger brackets on the piling mount. (As shown in figure A)
4. Separate piling mount swivel hinges from housing swivel hinges using supplied nylatron bushing. (As shown in figure A)
5. Insert $5/8" \times 4 1/2"$ bolts to secure housing and mast assembly to piling mount bracket. (As shown in figure A)





Note: $5/8" \times 4 1/2"$ Bolt and Nylatron bushing are located in piling channel.

REVISED 2/22/2017

STEP 4: ARM & BUNK ASSEMBLY

1. Attach arms to mast using (2) 5/8" x 5" bolts, lockwasher, and nut.
2. Attach cable to arm plate using (1) 5/8" x 5" bolt and spacer. (As shown in figure B)
3. Attach bunk boards to arms using (4) u-bolts and bunk board brackets.
4. Locate bunk boards so that you have 5" (minimum) clearance between your vessel and the mast. This clearance is needed to ensure that your vessel does not come in contact with the cable as it is lifted vertically.



STEP 5: HOIST & CABLE ASSEMBLY

1. Attach cable to PSI drive unit by loosening set screw located in drive spool.
(Drive spool may have to be rotated before loosening. To rotate drive spool rotate large drive pulley with your hand until the spool is in the desired location.)
2. Insert cable into hole located to the inside of the drive spool.
3. After cable is inserted past the set screw, tighten set screw onto cable.
(Pull slightly on cable to ensure cable is secure)
4. Wind cable onto the spool by keeping tension on the cable and running drive in the upward motion. (Be sure cable is wrapped neatly on the cable spool.)

